

Standard Operating Procedure

Oxidizers

Section 1 - Lab-Specific Information

Department: College of Engineering – Discovery Learning Labs

Date SOP was written: 10/29/2018

Date SOP was approved by PI/lab supervisor: Click here to enter a date.

Principal Investigator: Thomas Silman

Internal Lab Safety Coordinator/Lab Manager: Thomas Silman

Lab Phone: 414-288-4602

Office Phone: 414-288-5423

Thomas Silman 414-350-5432
Emergency Contact:

Engineering Hall – Discovery Learning Labs Complex

Location(s) covered by this SOP:

Oxidizers 1 Date: 10/29/2018



Section 2 – Type of SOP:

☐ Process ☐ Hazardous Chemical ☐ Hazardous Class

Section 3 – Physical / Chemical Properties and Uses

Physical / Chemical Properties:

CAS#: N/A

GHS Classification: Oxidizing Liquid or Oxidizing Solid

Molecular Formula: N/A

Form (physical state): Liquid or Solid

Color: N/A

Boiling Point: N/A

Flash Point: N/A

Lower Explosive Limit: N/A

Upper Explosive Limit: N/A

Relative Vapor Density: N/A

Uses:

Common oxidizers include Hydrogen peroxide, Nitric acid, Nitrate and Nitrite compounds, Perchloric acid and Perchlorate compounds, and Hypochlorite compounds, such as household bleach. Oxidizers have a wide variety of applications including cleaners and disinfectants, agricultural fertilizers, rocket propellant and fuel, and explosives.

Important Definitions:

- Oxidizing liquid- a liquid which, while in itself is not necessarily combustible, may generally by yielding oxygen, cause or contribute to the combustion of other material. Hydrogen peroxide, nitric acid, and nitrate solutions are examples of oxidizing liquids commonly found in a laboratory.
- Oxidizing solid- a solid which, while in itself not necessarily combustible, may generally by yielding oxygen, cause or contribute to the combustion of other material.

Section 4 - Potential Hazards

Oxidizer. Keep away from heat. Keep away from clothing and other combustible materials. Take any precaution to avoid mixing with combustibles. Store away from combustibles. Oxidizers can have other associated hazards, such as corrosive or toxic (e.g., Nitric acid, Sodium nitrite). Make sure that all of the potential hazards are understood before handling any chemical.





Section 5 – Personal Protective Equipment (PPE)

Respirator Protection:

If oxidizing liquids or solids are being used outside of a chemical fume hood, respiratory protection may be required. If this activity is absolutely necessary, contact EH&S so a respiratory protection analysis can be performed. Respirators should be used under any of the following circumstances:

- As a last line of defense (i.e., after engineering and administrative controls have been exhausted).
- When Permissible Exposure Limit (PEL) has exceeded or when there is a possibility that PEL will be exceeded.
- Regulations require the use of a respirator.
- An employer requires the use of a respirator.
- There is potential for harmful exposure due to an atmospheric contaminant (in the absence of PEL)
- As PPE in the event of a chemical spill clean-up process
- Lab personnel intending to use/wear a respirator mask must be trained and fit-tested. This is a regulatory requirement. Contact EH&S 8-8411 regarding respirator clearance.

Hand Protection:

Gloves must be worn. Use proper glove removal technique to avoid any skin contact. Nitrile gloves are recommended. Check the resources below for the most suitable glove.

NOTE: Consult with your preferred glove manufacturer to ensure that the gloves you plan on using are compatible with the specific oxidizing liquids or solids being used.

Refer to glove selection chart from the links below:

http://www.ansellpro.com/download/Ansell 8thEditionChemicalResistanceGuide.pdf

OR

http://www.showabestglove.com/site/default.aspx

OR

http://www.mapaglove.com/

Eye Protection:

ANSI approved properly fitting safety glasses or chemical splash goggles are required. A face shield may also be appropriate depending on the specific application.

Skin and Body Protection:

Laboratory coats must be worn and be appropriately sized for the individual and buttoned to their full length Laboratory coat sleeves must be of sufficient length to prevent skin exposure while wearing gloves. Personnel should also wear full length pants, or equivalent, and close-toed shoes. Full length pants and close-toed shoes

Oxidizers 3 Date: 10/29/2018



must be worn at all times by all individuals that are occupying the laboratory area. The area of skin between the shoe and ankle should not be exposed.

Hygiene Measures:

Wash thoroughly and immediately after handling. Rinse immediately contaminated clothing and skin with plenty of water before removing clothes.

Section 6 – Engineering Controls

Use of oxidizing liquids and solids should be conducted in a properly functioning chemical fume hood whenever possible. The chemical fume hood must be approved and certified by EH&S and have a face velocity between 85 – 125 feet per minute.

Section 7 - First Aid Procedures

If inhaled:

Move into the fresh air immediately. Consult a physician. If not breathing give artificial respiration and seek immediate medical attention.

In case of skin contact:

Immediately flush skin with plenty of water for at least 15 minutes while removing contaminated clothing and shoes. Wash any contaminated clothing before reuse. Thoroughly clean shoes before reuse. Consult a physician.

In case of eye contact:

Check for and remove any contact lenses. Rinse thoroughly with plenty of water for at least 15 minutes and consult a physician. Seek immediate medical attention.

If swallowed:

Do NOT induce vomiting unless directed by medical personnel. Never give anything by mouth to an unconscious person. Seek immediate medical attention.

Section 8 – Special Handling and Storage Requirements

- Do not over purchase; only purchase what can be safely stored in the laboratory.
- · Avoid contact with skin, eyes, and inhalation. Avoid inhalation of vapor or mist. Avoid formation of dust.
- Keep away from combustible materials. Keep away from sources of ignition No smoking.
- Keep containers tightly closed. Store in a cool, dry, and well-ventilated area away from incompatible substances such as flammable and combustible liquids.
- Keep cool and protected from sunlight.
- Opened containers of oxidizing liquids must be carefully resealed and kept upright to prevent leakage.
- Carefully follow manufacturer's instructions if oxidizing liquid needs to be vented during storage.



Section 9 - Spill and Accident Procedures

Chemical Spill Dial 8-1911

Immediately evacuate area and ensure others are aware of the spill. If there is an imminent threat of a fire, pull the nearest fire alarm station to evacuate the building and **dial 8-1911**. If the spill is minor and does not pose a threat to personnel, contact EH&S at 8-8411 during normal business hours (7:30 AM – 4:30 PM) for spill cleanup assistance (dial 8-1911 if spill occurs after hours and assistance is needed).

Chemical Spill on Body or Clothes:

Remove clothing and rinse body thoroughly in emergency shower for at least 15 minutes. Seek medical attention; dial 8-1911.

Chemical Splash into Eyes:

Immediately rinse eyes and inner surface of eyelid with water from the emergency eyewash station for 15 minutes by forcibly holding the eye open. Seek medical attention; **dial 8-1911**.

Section 10 – Medical Emergency

Life Threatening Emergency, After Hours, Weekends And Holidays:

Dial 8-1911

Non-Life Threatening Emergency:

Immediately report injury to supervisor and complete the First Report of Injury.

http://www.marquette.edu/riskunit/riskmanagement/documents/Employee First Report of Incident.pdf

Section 11 – Waste Disposal Procedures

Label Waste:

When possible, do not mix oxidizer waste streams with flammable or combustible waste. Make sure the waste container(s) is properly labeled; label should indicate all of the contents of the container. EH&S provides hazardous waste labels free of charge, contact dennis.daye@marquette.edu to obtain labels.

Store Waste:

Store hazardous waste in closed containers, and in a designated area.

Dispose of Waste:

Complete a Chemical Waste Pickup Request Form to arrange for disposal by EH&S. Contact dennis.daye@marquette.edu or visit the EH&S webpage for questions.

http://www.marquette.edu/riskunit/environmental/documents/waste_disposal_form.pdf

Oxidizers 5 Date: 10/29/2018



Section 12 - Safety Data Sheet (SDS)

A current copy of the SDS for the specific oxidizing liquid or solid being used must be made available to all personnel working in the laboratory at all times. To obtain a copy of the SDS, refer to Marquette's MSDS library http://www.marquette.edu/riskunit/environmental/documents/msds library.pdf or contact the chemical manufacturer. Many manufacturers' SDSs can be found online on websites such as Sigma-Aldrich (http://www.sigmaaldrich.com/united-states.html) or Siri MSDS Index (http://hazard.com/msds/).

Section 13 – Protocol/Procedure (Additional lab protocol may be added here)

- Use in the smallest practical quantities for the experiment being performed.
- Work must be conducted in a chemical fume hood if the chemical is irritating to the eyes or respiratory system, and/or is toxic by inhalation.
- Containers should remain closed when not in use.
- Containers should be labeled appropriately. Label should indicate the name of the chemical(s) in the container. Avoid using chemical abbreviations (acceptable if a legend is present in the lab) and formulae.
- Containers should be in good condition and compatible with the material.
- Avoid using ignition sources (flame burners or any open flame source, hot plates, electrical equipment with frayed or cracked wiring, etc.) and/or creating static electricity in areas where oxidizing chemicals are being used.
- Transport all oxidizing liquids and solids in secondary containment, such as polyethylene or other non-reactive acid/solvent bottle carrier.
- Oxidizers must be segregated from incompatible materials such as flammable and combustible materials.
 Incompatibilities will be noted in Section 10 of the SDS, "Stability and Reactivity".

Click here to enter text.

NOTE: Any deviation from this SOP requires approval from PI.

Oxidizers 6 Date: 10/29/2018



Section 14 – Documentation of Training (signature of all users is required)

- Prior to conducting any work with oxidizers, designated personnel must provide training to his/her laboratory
 personnel specific to the hazards involved in working with this substance, work area decontamination, and
 emergency procedures.
- The Principal Investigator must provide his/her laboratory personnel with a copy of this SOP and a copy of the SDS provided by the manufacturer.
- The Principal Investigator must ensure that his/her laboratory personnel have attended appropriate laboratory safety training or refresher training within the last one year.

I have read and understand the content of this SOP:

Name	Signature	Date
Click here to enter text.		Click here to enter a date.
Click here to enter text.		Click here to enter a date.
Click here to enter text.		Click here to enter a date.
Click here to enter text.		Click here to enter a date.
Click here to enter text.		Click here to enter a date.
Click here to enter text.		Click here to enter a date.
Click here to enter text.		Click here to enter a date.

Oxidizers 7 Date: 10/29/2018